



How to program your ADB remote to control your TV.

- 1 Turn on your TV.
- 2 On the remote control, press **TV** once; it will blink once.
- 3 Press and hold **RCU SETUP** until the TV key blinks twice.
- 4 Type **991**. The TV key will blink twice.
- 5 Press and release the **CH+** key repeatedly, then stop when the TV turns off.
- 6 Press **RCU SETUP** once to lock in the code. The LED will blink twice to show that the code is saved.
- 7 Press **STB**.
- 8 Press **RCU SETUP** until STB blinks twice.
- 9 Enter **995**
- 10 Press **POWER**.
- 11 Press mode key for device you wish to turn on first (**TV**).
- 12 Press **POWER**.
- 13 Press mode keys for additional device to be turned on, such as **DVD**, then press **POWER**.
Repeat for as many devices as needed.
- 14 Press **STB**
- 15 Press **RCU SETUP** until STB blinks twice.

To search for the codes of your other devices, repeat steps 1 through 6, but substitute the appropriate key (e.g., VCR, DVD, AUD, or STB) for the device you are searching for.
NOTE: If the TV does not turn on during step 6, then slowly press and release CH- to go back through the codes, then press RCU SETUP when the TV turns on

KALONA COOPERATIVE TELEPHONE COMPANY

Providing world class technology services ~with a home town touch

Call: 656-3668
Click: KCTC.net
Visit: 510 B Ave